

WorkForce® Pro WP-4590

Start Here


Read these instructions before using your product.

1 Unpack




Caution: Do not open ink cartridge packages until you are ready to install the ink. Cartridges are vacuum packed to maintain reliability.

Remove all tape and protective materials, including the foam and plastic inside the printer.




2 Turn on

- 1 Connect the power cord to the back of the printer and to an electrical outlet.



Caution: Do not connect to a computer yet.

- 2 Press the power button.




3 Select settings

- 1 To select **English** as your language, press **OK**.
If you want to change the language, select it and press **OK**.
- 2 Select your country and press **OK**.
- 3 Select **Summer** if Daylight Saving Time is in effect (spring through summer); otherwise, select **Winter**. Press **OK**.
- 4 Select the date format and press **OK**.
- 5 Use the numeric keypad to set the date and press **OK**.
- 6 Select **12h** (AM/PM) or **24h** and press **OK**.
- 7 Use the numeric keypad to set the time and press **OK**.


Note: You can change the date and time settings by pressing **Setup**, selecting **Printer Setup**, then selecting **Date/Time**.

4 Install ink cartridges


- 1 Open the front cover.




- 2 Unpack the four ink cartridges.



- 3 Shake each cartridge as shown for about 5 seconds.




- 4 Install each cartridge in the correct slot for its color. Push each cartridge in until it clicks.



412213600

EPSON®
EXCEED YOUR VISION

- 5 Close the front cover.



The printer starts priming the ink. This takes about 12 minutes. When you see a confirmation message on the product's LCD screen, priming is complete.


Note: The included cartridges prime the printer and print about 1000 black pages/900 color pages. Actual page count will vary.

Caution: Don't turn off the printer or open the cover while it is priming or you'll waste ink.


5 Load paper in the cassette

You can load letter-, A4-, or legal-size plain paper in the cassette. For instructions on loading envelopes and special paper in the rear MP tray, see the online *User's Guide*.


- 1 Pull out the paper cassette.




- 2 Slide the edge guides outward, and position them for the size of paper you are using.



Note: If loading legal-size paper, extend the cassette as shown.




- 3 Insert the paper with the printable side facedown.




Note: Make sure the paper is loaded against the edge guide and not sticking out from the end of the cassette.

- 4 Slide the edge guides against the paper, but not too tight. Make sure the paper is under the tabs on the edge guides.




- 5 Gently insert the paper cassette at the bottom of the printer.




Note: The paper may slide forward slightly as you insert the cassette. This is normal.

- 6 Extend the output tray and raise the paper stopper as shown. (Do not raise the paper stopper for legal-size paper.)



6 Connect the fax line

To fax, connect the included phone cord to a telephone wall jack and to the LINE port on the back of your product. To connect a telephone or answering machine, use the EXT. port on your product. See the online *User's Guide* for more details.



Note: If you're connecting to a DSL phone line, you must use a DSL filter or you won't be able to fax. Contact your DSL provider for the necessary filter.

7 Install software

If you're using the product as a laser printer replacement, you do not need to install any Epson drivers.


Note: To use the Fax Utility and Epson Status Monitor, install the standard Epson driver. If you want to install multiple drivers, repeat the software installation process as necessary. For more information, see your online *User's Guide*.

If you want to install any Epson drivers, follow the steps below.


Note: If a computer does not have a CD/DVD drive, you can download the software from the Epson website (see "Epson technical support").

Caution: Be sure to close any other programs, including any screen savers and virus protection software, before beginning this software installation.


- 1 Make sure the printer is **NOT CONNECTED** to a computer.



Windows®: If you see a Found New Hardware screen, click **Cancel** and disconnect the USB cable. You can't install your software that way.




- 2 Insert your product CD.



- 3 **Windows:** If you see the AutoPlay window, click **Run Setup.exe**. If you see the User Account Control screen, click **Yes** or **Continue**.

Mac OS® X: Double-click the  **Epson** icon.

- 4 Click **Install** (Windows) or **Continue** (Mac OS X) and follow the instructions on your computer screen.



- 5 **Windows:** When you see the Select Your Printer Driver Type screen, select your desired driver. Then click **Next** and follow the instructions on your computer screen.






Mac OS X: The standard Epson driver installs automatically. If you want to install the PostScript driver, go to www.epson.com/wp4590downloads. Then download and install the file.

Any problems?

The printer makes a loud noise and you see an error message when you turn it on.

Make sure you remove the protective foam and plastic from inside the printer.

Network setup was unsuccessful.


- To print a network status sheet, press the  **Setup** button, select **Network Settings**, then select **Confirm Network Settings**. Press the  **B&W** or  **Color** button.
- When using TCP/IP, make sure your network's DHCP option is enabled. If you have assigned a static IP address, make sure it is not being used by another device.
- Try changing the network cable and/or the network port connection to your router.
- Disable the firewall temporarily to see if that may be causing the problem. Contact your firewall manufacturer for assistance.
- If you have assigned a static IP address, make sure it is not being used by another device.

The printer's screen is dark.

Press any button to wake the printer from sleep mode.

Setup is unable to find my printer after connecting it with a USB cable.

Make sure it is securely connected as shown:



Printing problems

Printing stops when an ink cartridge is expended. If a cartridge is expended, you must replace it to continue printing.

Print quality problems

- Make sure your paper is loaded printable side down in the cassette (usually the whiter, brighter, or glossy side).
- If you notice light or dark bands across your printouts or they are too faint, run a nozzle check to see if the print head needs cleaning. See the online *User's Guide* for more information.
- The ink cartridges may be low on ink. Check your cartridge levels and replace cartridges, if necessary. See the online *User's Guide* for more information.

Any questions?

On-screen help with your software

Select **Help** or **?** when you're using your software.

User's Guide

Click the icon on your desktop (or in the **Applications/Epson Software/Guide** folder in Mac OS X) to access the online *User's Guide*, software downloads, Epson Supplies Central®, and more (requires an Internet connection). If you don't have a User's Guide icon, you can install it from the CD or go to the Epson website, as described below.

Epson technical support

Visit **epson.com/support** (U.S.) or **epson.ca/support** (Canada) where you can download drivers, view manuals, get FAQs, or e-mail Epson.

You may also speak with a support specialist by calling:

- **U.S.:** (562) 276-4382, 6 AM to 8 PM, Pacific Time, Monday through Friday, and 7 AM to 4 PM Saturday
- **Canada:** (905) 709-3839, 6 AM to 8 PM, Pacific Time, Monday through Friday

Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

Software technical support

ABBYY® FineReader®
(408) 457-9777
www.abbyyusa.com
support@abbyyusa.com

Recycling

Epson offers a recycling program for end of life hardware and ink cartridges. Please go to **www.epson.com/recycle** for information on how to return your products for proper disposal.

Need paper and ink?

Try Epson paper with DURABrite® Ultra Ink for professional results. For the right supplies at the right time, you can purchase them at Epson Supplies Central at **www.epson.com/ink3** (U.S. sales) or **www.epson.ca** (Canadian sales). You can also purchase supplies from an Epson authorized reseller. To find the nearest one, call 800-GO-EPSON (800-463-7766).

DESIGNED *for* EXCELLENCE™
Epson printers, ink and specialty papers.

Genuine Epson paper

Epson offers a wide variety of business and photo papers to meet your needs; visit Epson Supplies Central for more information.



Presentation Paper Matte
Smooth, non-glare, instant-drying paper ideal for reports, newsletters, and graphical presentations.

Genuine Epson inks



Look for the numbers below to find your cartridges. It's as easy as remembering your number!



WorkForce Pro WP-4590 ink cartridges

Color	High-capacity	Super High-capacity
Black	676XL	711XXL
Cyan	676XL	711XXL
Magenta	676XL	711XXL
Yellow	676XL	711XXL

Epson Connect



Get instant, wireless printing of photos and attachments right from smartphones, iPads, tablets, and other popular mobile devices. See **www.epson.com/connect** for details.



WorkForce, Epson Supplies Central, and DURABrite are registered trademarks, and Epson Exceed Your Vision is a registered logomark of Seiko Epson Corporation. Designed for Excellence is a trademark of Epson America, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.